
How do I specify a party wall?

Click on the wall you want to specify and use the drop down menu to select whether the other side of this wall is a heated or unheated space. By default the drop down will be set to *Outside*.



For more information on this topic, see our guide on creating floor plans.

Revision #14
Created 8 November 2024 13:01:22
Updated 7 October 2026 13:27:23 by Emma