

# How do I specify a party wall?

---

Click on the wall you want to specify and use the drop down menu to select whether the other side of this wall is a heated or unheated space. By default the drop down will be set to *Outside*.

For more information on this topic see our guide on [creating floor plans](#).

---

Revision #11

Created 8 November 2024 13:01:22

Updated 30 June 2026 08:17:41 by Rhys Gwynn